




DuPont Automotive Finishes

## DuPont™ ChromaClear® 7900S™ Multi-Use Clear

### Description

ChromaClear® 7900S™ is a versatile, two-component, urethane clearcoat for use in spot, panel and overall refinishing of OEM base/clear finishes. ChromaClear® 7900S™ provides easy application and good build in two coats, and is well suited for cross-flow and downdraft booth conditions.


### General Information



#### Components

ChromaClear® 7900S™ Multi-Use Clear  
 ChromaClear® 7975S™ Fast Activator-Reducer  
 ChromaClear® 7985S™ Medium Activator-Reducer  
 ChromaClear® 7995S™ Slow Activator-Reducer

	65°F	75°F	85°F	95°F
<b>Panel</b>	7975S™	7975S™	7985S™	7995S™
<b>Multi-Panel</b>	7975S™	7985S™	7995S™	7995S™
<b>Overall</b>	7985S™	7995S™	7995S™	7995S™



#### Mix Ratio/Viscosity

Combine the components either by volume or weight and then mix thoroughly.


	Volume	Weight (cumulative qt)
ChromaClear® 7900S™	3	670.2 grams
ChromaClear® 7975S™/7985S™/7995S™	1	913.4 grams

#### Viscosity

15 - 17 seconds in a Zahn #2 (DuPont M-222) cup.

#### Tips for Success


Use mixing stick for accurate measurements.



#### Pot Life

2 hours at 70°F.

**Note:** When using MasterTint® 389S™, pot life is reduced to 1 hour at 70°F.



#### Additives

Accelerator: MasterTint® 389S™ Fast Dry Accelerator; use ½ ounce per ready-to-spray quart. Caution: Use of accelerator under force dry (bake) conditions may lead to dieback.


Fish Eye Eliminator: DuPont 459S™ or 659S™; use ¼ - ½ ounce per ready-to-spray quart.

Enhancer: DuPont 19379S™; use up to 2 ounces per ready-to-spray quart

Flex Additive: Add 1-2 ounces Plas-Stick® 2350S™ Flexible Additive per ready-to-spray quart of activated clearcoat or use Plas-Stick® 2350S™ as described below:


	Volume	Weight (cumulative qt.)
ChromaClear® 7900S™	10	638.3 grams
ChromaClear® 79X5S™ (X=7, 8 or 9)	3	844.93 grams
Plas-Stick® 2350S™	1	909.93 grams

# DuPont™ ChromaClear® 7900S™ Multi-Use Clear



## Basecoats

ChromaBase® Basecoat  
ChromaPremier® Basecoat



## Substrates

ChromaBase® Basecoat  
ChromaPremier® Basecoat  
DuPont 222S™ Mid-Coat Adhesion Promoter for blend areas



## Surface Preparation

For application over a properly prepared basecoat repair:

- Mask the entire vehicle to prevent overspray from sticking.
- Allow basecoat to dry 15 - 30 minutes.
- Extend basecoat dry time to 30 minutes when applying several base color coats and/or in cooler shop conditions.




## Gun Setups\*

### Conventional

Siphon Feed: 1.5 mm - 1.7 mm (.059" - .067")  
Gravity Feed: 1.4 mm - 1.6 mm (.055" - .063")

### HVLP

Siphon Feed: 1.5 mm - 1.7 mm (.059" - .067")  
Gravity Feed: 1.4 mm - 1.6 mm (.055" - .063")



## Air Pressure\*

### Conventional

Siphon Feed: 40 - 45 psi @ the gun. 45 - 50 psi @ the gun.  
Gravity Feed: 35 - 45 psi @ the gun. 40 - 45 psi @ the gun.

### HVLP


6 - 8 psi @ the gun cap. 8 - 10 psi @ the gun cap.

\*The listed setups cover the usual range for various application equipment. For information on specific manufacturers' equipment, see the "Equipment Information" Section in the Appendix of the ChromaSystem™ Technical Manual.



## Application

Apply 2 medium-wet coats.



## Flash/Dry Times

### Air Dry

Flash between Coats: 10 minutes.  
Dust Free: 15 - 20 minutes.  
Time to Handle (Assemble): Overnight.  
Time to Polish: Overnight.  
Time to Stripe: Overnight.  
Time to Deliver: Overnight.  
Time to Decal: After 72 hours.


## DuPont™ ChromaClear® 7900S™ Multi-Use Clear

### Flash/Dry Times (continued)

#### Force Dry

Flash before Force Dry:	0 minutes.
Cycle Time:	30 minutes @ 140°F.
Dust Free:	At cool down.
Time to Handle (Assemble):	After cool down.
Time to Polish:	2 - 3 hours after cool down.
Time to Stripe:	2 - 3 hours after cool down.
Time to Deliver:	2 - 3 hours after cool down.
Time to Decal:	24 - 72 hours.

*Infrared Dry* Refer to the Infrared Guide for setup recommendations.




### Blending

Panel repair is the approved procedure for clearcoat warranty repairs. This allows the refinisher to attain the recommended film builds. If the refinisher chooses to blend, use ChromaSystem 19301S™ Blender.

- After the final coat of clearcoat, step-out the coating by mixing 1 part ChromaSystem 19301S™ Blender to 1 part of the remaining material and taper the blend with the resulting mixture.
- Place ChromaSystem 19301S™ Blender in a clean spray gun and taper the blend edge for final melt-in of the blended edge.


### Tips for Success

*For sail panel blending, be sure DuPont 222S™ is applied beyond the intended clearcoat area.*



### Recoatability/Re-repair

ChromaClear® 7900S™ may be recoated during any stage of dry or cure. If recoating after 24 hours, scuff sand with 1200 - 1500 grit.



### Polishing

#### Optimum Times

Air Dry:	Overnight.
Force Dry:	2 - 3 hours after cool down.

#### Sanding

Use 1500 grit wet or finer. Or use P1500 DA or finer.

#### Compounding

Use finishing compound. Apply a thin ribbon of material to the area to be polished. Use a double-sided wool polishing pad or a foam pad. Maintain air polisher or variable speed buffer at 1500 - 1800 rpm. Remove excess finishing compound with a clean soft cloth prior to applying finishing polish.


#### Polishing

Use finishing polish (shake well before using). Apply a ribbon of material to work a 2 - 3 foot square area. Use a foam pad or a terry cloth cover. Maintain a variable speed buffer or an orbital polisher at 1200 - 1800 rpm. Keep the polisher/buffer moving at all times. Overlap each pass approximately 50%. As finishing polish begins to dry, stop polishing. Wipe off excess finishing polish with a clean soft cloth. Hand buff with a clean soft cloth as a finishing touch.

### Tips for Success

- Do not use medium to heavy-duty compounds. Use clean cloths and pads to insure that the clear does not get scratched with dirt particles from old or re-used cloths or pads.
- Do not wax for the first 120 days after painting.

## DuPont™ ChromaClear® 7900S™ Multi-Use Clear



---

### Cleanup

Clean spray equipment as soon as possible with DuPont Lacquer Thinner.

---

### Physical Properties

VOC: 4.3 lbs/gal ready-to-spray.

Theoretical Coverage: 604 sq. ft. per ready-to-spray gallon at 1 mil.

Weight Solids: 44.5% ready-to-spray.

Volume Solids: 37.7% ready-to-spray.

Recommended Dry Film Thickness: 1.8 - 2.2 mils in 2 coats.

Flash Point: See MSDS.

---

### VOC Regulated Areas

These directions refer to the use of products which may be restricted or require special mixing instructions in VOC regulated areas. Follow mixing and usage recommendations in the VOC Compliant Products Chart for your area.

---

### Safety and Handling

WEAR A POSITIVE-PRESSURE, SUPPLIED-AIR RESPIRATOR (NIOSH APPROVED TC-19C), EYE PROTECTION, GLOVES AND PROTECTIVE CLOTHING WHILE MIXING ACTIVATOR WITH PAINT, DURING APPLICATION AND UNTIL ALL VAPORS AND SPRAY MIST ARE EXHAUSTED. Follow respirator manufacturer's directions for respirator use. INDIVIDUALS WITH HISTORY OF LUNG OR BREATHING PROBLEMS OR PRIOR REACTION TO ISOCYANATES SHOULD NOT USE OR BE EXPOSED TO VAPOR OR SPRAY MIST. Do not permit anyone without protection in the painting area.